

# Rubber Sport Flooring

## MAINTENANCE INSTRUCTIONS

### What You Need:

- Zogics Rubber Floor Cleaner & Degreaser
- Broom, Vacuum, or Dust Mop
- Wet Vacuum
- Mop & Bucket
- Autoscrubber
- Blue Scrubbing Pads

### Missing anything?

Follow the link below to stock up on all of the products and equipment needed to keep your flooring maintained, from mops & cleaner to vacuums and autoscrubbers.

[SHOP SUPPLIES](#)

Or visit [zogics.com/clean-rubber-flooring](https://zogics.com/clean-rubber-flooring)

### Initial Cleaning

- 1 Remove all loose debris by vacuuming, sweeping or by using a dust mop.
- 2 Wet scrub the floor with an autoscrubber fitted with a soft nylon brush or Namco Blue Cleaner Pad. We recommend using Zogics Rubber Sport Flooring Cleaner & Degreaser—a neutral pH (7–9) cleaner designed for rubber floor cleaning needs. Dilute the solution 10 oz. per gallon of water. DO NOT flood the floor with water.
- 3 Use a wet vacuum or mop to pick up the cleaning solution from the floor, then rinse with clean water. Again, do not flood the floor. The rinse water should then be wet vacuumed or mopped from the floor.
- 4 Allow the floor to dry before foot traffic.

### Regular Maintenance (Daily)

- 1 Remove all loose debris from your flooring with a vacuum, broom, or dust mop.
- 2 Dilute 1–2 oz. of Zogics Rubber Sport Flooring Cleaner & Degreaser per gallon of water.
- 3 Apply product evenly to rubber flooring with a mop.
- 4 Allow product to sit on flooring for 5–7 minutes.
- 5 Mop up excess product, then rinse flooring with clean water. Mop again to clear flooring of water, then air dry.

### Deep Cleaning (Weekly)

- 1 Remove all loose debris from your flooring with a vacuum, broom, or dust mop.
- 2 Dilute 10 oz. of Zogics Rubber Sport Flooring Cleaner & Degreaser per gallon of water.
- 3 Wet scrub flooring with solution and autoscrubber fitted with a Namco Blue Scrubbing Pad. DO NOT flood the floor with water.
- 4 Allow product to sit on flooring for 5–7 minutes.
- 5 Use a wet vacuum to pick up cleaning solution from flooring.
- 6 Rinse floor with clean water and let air dry.

