

Bottle Rocket Mop

Maintenance Instructions

1. Do not use this tool with vinegar. The acidity will break down the seals causing leaks.
2. Remember to release the pressure from the tank when you are finished cleaning.
3. After cleaning, flush out the spray nozzle tool with warm water.
4. Use caution when transporting the mop from place to place.



MICROFIBER
WHOLESALE