



LEARN MORE AT ZOGICS.COM

# Disinfectant-Ready Dry Wipe Systems

*Simple, six-step systems for creating and having wipes on hand in your facility.*

- Easy-to-use
- Refillable, portable dispensing bucket
- Creates effective disinfectant wipes for use at any facility type

## Directions for Use:

1. Lift the lid from off the bucket
2. Place one (1) roll or flat dry wipes inside the refillable bucket
3. Pour a quarter to a third of a gallon of disinfectant over the wipes
4. Close lid and allow 20 minutes for the wipes to absorb the cleaning solution
5. Pull the leading wipe from the center of the roll and feed it through the lid and close the lid (in round bucket)
6. Open the lid to use your wipes

*For both systems, refill dry wipes and extra buckets are available.*